





Top Zip Access

that opens away from the body for ease of access and security on the go, with slim shock absorbent dividers

Accessories Pouch

is designed to organise your cables, batteries and more, so that everything is to hand when needed

Accessories Pouch

fits onto the bag, but is removable and can be used as separate sling bag for camera (or everyday) kit on the go

Tough Weatherproof air textured yarn outer

with waterproof zips covers shock absorbent body, with rain cover for wettest days



PRODUCT SPECIFICATIONS

Feature	S30	S36	S38
External Dimensions	335 × 220 × 220mm	380 × 230 × 255mm	400 × 220 × 280mm
Hand Luggage (vary by airline)	Most Airlines (always check)	Most Airlines (always check)	Most Airlines (always check)
Internal Dimensions	300 × 100 × 210mm	360 × 110 × 240mm	380 × 120 × 265mm
Litres	7L (+1L Pouch)	10L (+1L Pouch)	13L (+1L Pouch)
Camera Body (Lens Attached)	APSC to Full Frame	APSC to Full Frame	APSC to Full Frame
Additional Lenses	1-2 lenses (up to 24-70mm f2.8)	3-4 lenses (up to 70-200mm f2.8)	3-4 lenses (up to 70-200mm f2.8)
Tablet/Laptop (Compartment Size)	11" Tablet (260 × 15 × 180mm)	13" laptop (320 × 15 × 220mm)	14" laptop (350 × 15 × 240mm)
Tripod Holder	Yes	Yes	Yes
Power Cable Slot	Yes	Yes	Yes
X-Body Strap	Yes	Yes	Yes
Accessories Pouch	Yes	Yes	Yes
RFID Protected Pocket	Yes	Yes	Yes
Weight	1.3kg	1.6kg	1.9kg



Slip a power bank into your bag and you can have a cable feeding power directly through a slot in the side of the bag to your phone/camera on the go

